

INSTALLATION GUIDE

Fast. Clean. Professional.

01 APPLICATION SCOPE



- KOVON Architectural Film is designed primarily for interior applications.
- Proper installation ensures optimal adhesion, durability and visual consistency.

02 INSTALLATION ENVIRONMENT



- Recommended Temperature: 18°C - 25°C.
- Working Range: 12°C - 35°C.
- Substrate must be completely dry.
- Ensure sufficient lighting during installation.
- Maintain a clean, dust-free environment.

Sudden temperature fluctuations after installation may cause bubbling or joint separation.

03 SUBSTRATE REQUIREMENTS



All substrates must be:

- Clean and free of dust, oil, and moisture.
- Smooth, even, and structurally stable.
- Properly prepared before installation.

Typical Substrates:

MDF / Plywood / Wood / Stainless Steel / Aluminium / Glass
/ Painted surfaces

04 SURFACE PREPARATION



- Sand surface.
- Fill joints or uneven areas with putty.
- Clean thoroughly with alcohol or dry cloth.
- Ensure complete dryness before installation.

Proper preparation is critical for long-term adhesion.

05 PRIMER TREATMENT



Primer is recommended for:

- Cut edges.
- Porous substrates (e.g. MDF).
- Corners and joints.

Apply 2-3 coats and allow full drying before installation.

06 INSTALLATION METHOD



1. Align film direction.
2. Gradually remove release liner.
3. Apply using felt squeegee from center outward.
4. Remove air with firm pressure.
5. Reinforce edges and corners.

Apply heat carefully for curves. Avoid overstretching.

07 JOINT & PATTERN CONSIDERATION



- Install films in consistent direction.
- Avoid mixing different batches.
- Minor colour variation may occur.
- Pre-check alignment before installation.



Installation should be carried out by trained professionals.

Product performance may vary depending on substrate and site conditions.